

BLUETOOTH MOBILE SPEAKER

User's Manual



E-Boda Beat 100

Introduction

Thank you for purchasing the Bluetooth Mobile Speaker, E-Boda The Beat 100. You can use this item with your smartphone or tablet to stream music, and enjoy hands free calling. In order to get the best results when using this device, please read this manual first before using.

Features

- Volume and song control.
- Stunning sound clarity.
- Ultra portable design.
- Great for parties.
- Allows you to make and answer phone calls.

Specifications

Loudspeaker: 4 Ω 3W

Built-in Power: Li-ion 400mah

Dimensions: 72MM(W)*72MM(L)*63MM(H)

SNR: 80 \pm 3db

Wireless Working Frequency:2.402-2.480GHz

Wireless Transmission Distance: up to 10m

Weight: 165g

Speaker Dimension: 45mm

Charging Time: 1-2 hours

Package Contents

Bluetooth Mobile Speaker



3.5mm audio cable



USB Charging Cable



User's Manual




Important Safety Precautions

When using your Bluetooth Mobile Speaker, basic safety precautions should always be followed, including the following:

1. To avoid electrical hazards, do not expose to water or moisture.
2. Keep this product and its charging cable away from excessive heat.
3. Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
4. Do not disassemble your device.
5. Only use your device on a flat, stable surface.

A Quick Look at Your Device



1. Previous

Press to access the last track in a playlist. Press and hold to lower the volume.


2. Phone

Press this button to activate the speaker phone function. When music is playing, press to play or pause a track.

3. Next

Press to access the next track in a playlist. Press and hold to increase the volume.

A Quick Look at Your Device (continued)



1. Charging Port

You can plug one end of the included USB Charging Cable into this jack, while plugging the other end into a USB port on your computer in order to charge your speaker's built in lithium battery.

Aux in

Plug in the supplied audio cable into the speaker. The 3.5mm jack is connected to your device.

2. ON/OFF Switch

Slide this switch to the ON position to power on your speaker. Slide this switch to the OFF position to power off your speaker.

Charging Your Speaker

1. Connect one end of the included USB charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable USB port on your computer to recharge your speaker's internal rechargeable battery.

NOTE: The internal battery of your speaker takes approximately two hours to charge when completely drained.

2. When charging, a red LED light will illuminate to indicate that the unit is charging. The red light will turn off when your unit is fully charged.

Understanding the LED Status Lights

When Charging Your Speaker

Solid Red LED = Charging

Red LED OFF = Charge Complete

When Pairing Your Speaker to a Bluetooth Audio Source

Blinking Blue LED: Bluetooth not connected. (Ready to pair.)

Solid Blue LED: Bluetooth connected.

Pairing Bluetooth Devices to Your Speaker

In order to pair your Bluetooth audio device to your E-Boda The Beat 200 for the first time, follow the steps below:

- 1). Make sure your Bluetooth audio source is held within three meters of your speaker.
- 2). Slide the ON/OFF switch on your speaker to the ON position.




The LED light will blink blue to indicate that you have entered pairing status.

- 3). Go to the Bluetooth Manager of your Bluetooth audio source. Please refer to the User's Manual of your Bluetooth audio source for more information.

- 4). Search Bluetooth devices and select your speaker to start connecting.
- 5). Enter “0000” if your device asks for the PIN code.
- 6). Once paired, the blue LED light will turn on steadily and you can use your speaker to listen to audio from you Bluetooth sound source.

Using the Hands-Free Function

When a smartphone is connected to your speaker follow the steps below to take calls hands-free.

1. Press “  ” to pick up the call.
2. Press and hold “  ” for 2 sec to reject the call.
3. During a call: Press “  ” again to hang up the call.

Troubleshooting

| | |
|---|--|
| The speaker doesn't connect to device | Speaker needs to be connected/re-paired to device |
| A tone is heard every few seconds | Speaker needs to be charged |
| The speaker will not power on | Speaker needs to be charged |
| The speaker doesn't control track(s)/volume | Speaker needs to be in Bluetooth mode for full control |
| The speaker distorts at high volume | The devices' volume needs to be lowered |